

Remove Fractured Screw Screw Remover! No Worries About Fractured Screw


SR kit

SR kit is consisted of various tools designed to remove the fracture screw quickly and safely.
(1,200 RPM without irrigation)

Key Points of Neo Screw Remover kit

- 1. Remove fractured screw without damaging the fixture or pulling out the fixture.
- 2. Fractured screw can be removed in 3minutes.
- 3. Various implant system can be applied to Neo Screw Remover kit.
- 4. Screw with excessive torque can be removed with ratchet.

How to Use



8]gfM Jrc XU'6i HfYzrn#UJuf
Pv""\$&-'')&(*'
k k k "Vi HfYzrn]U]Uwca !]bz4 Vi HfYzrn]U]Uwca

